
Operation Manual

Desk-Lite 121



KINO FLO[®]
Lighting Systems

Fixture Assembly




DES-121-120

Kino Flo Desk-Lite 121, 120vac
Kino Flo Desk-Lite 121, 230vac


Fixture includes Louver and mounting screws.

Lamp Insertion



Turn power off before inserting or changing out lamps.

Ensure the black insert on the lamp holder is aligned vertically to accept a lamp.



Insert the lamp into the lamp holder and rotate $\frac{1}{2}$ turn.

Louver Placement



The Louver is held in place by Velcro tabs located at each corner of the louver.



Fixture Operation



On/Off switch is lighted when power is present.

Turn power off before inserting or changing lamps.

Fuse: Replace with 2.0A time delay fuse.

Applying Gels and ND



Option #1

Cut gel or Neutral Density filter to 13.5" x 4" (34 x 10cm).



Use adhesive tape to secure the gel to the outside of the fixture.

Ensure that the air vents are not obstructed.



Option #2

Cut the gel to 12.25" x 3.25" (31 x 8cm) and place it inside the fixture with the natural curl of the gel pointing down.



Insert the Louver to hold the gel in place.

Fixture Mounting



Adjustable hinge mount has two screw holes for mounting the fixture to a flat surface.



Screws for mounting are included with the fixture.



Fixture hinge tension is adjusted by the central Phillips head screw.

Fixture Components and Lamps



LVR-D121-B
12" Desk-Lite 121
Louver / Black





Lamps:

122-K29 12" Kino KF29


122-K55 12" Kino KF55

Fixture Specifications



Model	A	B	C	D	E	F
DES-121-120	13.25" 330mm	2.5" 63mm	2.5" 64mm	3" 76mm	3.5" 89mm	3.75" 95mm

Fixture Weight w/ lamp: 1.6 lb / 0.75 kg



Input voltage: 120vac or 230vac 50/60Hz
 Output Frequency: 48 kHz
 Lamp Type: F8T5 12" (305mm)
 Amperage: 0.30 Amps at 120vac
 0.10 Amps at 230vac
 Lamp switching: On/Off

For latest Warranty information and Certifications,
 see Kino Flo website at www.kinoflo.com.

Environmental: Disposal of Old Electrical & Electronic Equipment.



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. This product is made of recyclable materials and should be disposed of in accordance with local and state regulations.