
Operation Manual

Remote Dimmer/Lamp Selector DIM-5



KINO FLO®
Lighting Systems

DIM-5 Used as Dimmer

The **DIM-5** is a hand-held dimmer with a 15ft (3 meter) cable. It is used as a manual “**Dimmer**” to dim the light level of the following products:

- Diva-Lite 400 & 200
- ParaBeam 400 & 200
- Parazip 400 & 200

NOTE: The remote plug-in feature on the fixtures was introduced in Mid-2003 models. If the unit does not have the remote dimmer plug-in, the remote dimmer cannot be used.



Diva-Lite 400 & 200



ParaBeam 400 & 200



ParaZip 400 & 200

DIM-5 Dimmer Operation



Insert one end of cable into receptacle on the **DIM-5**.

No batteries are required to operate the **DIM-5**; the power is drawn from the Fixture.



Diva-Lite 400/200

Insert other end of the **DIM-5** cable into the receptacle marked: **REMOTE DIM**.

The **DIM-5** will automatically over-ride the on-board Dimmer.



ParaBeam 400/200

On the ParaBeam insert other end of the **DIM-5** cable into the receptacle marked: **REMOTE DIM**.

The **DIM-5** Dimmer will automatically over-ride the on-board Dimmer.



ParaZip 400/200

Insert other end of the **DIM-5** cable into the receptacle marked: **REMOTE DIM**.

The **DIM-5** Dimmer will automatically over-ride the on-board Dimmer.

DIM-5 Used as Lamp Selector

DIM-5 can also work as a “**Lamp Selector**” to control the light level of the following non-dimming products by switching on/off individual lamps.

- VistaBeam 600 & 300
- Image 85 & 45

NOTE: The remote plug-in feature on the fixtures was introduced in Mid-2003 models. If the unit does not have the remote dimmer plug-in, the remote dimmer cannot be used.



VistaBeam 600



VistaBeam 300



Image 85



Image 45

DIM-5 Lamp Selector Operation



Insert one end of cable into receptacle on the **DIM-5**.

No batteries are required to operate the **DIM-5**; the power is drawn from the Fixture.



VistaBeam



Image

Insert other end of the **DIM-5** Cable into the receptacle marked: **REMOTE**

The **DIM-5** will automatically over-ride the on-board Lamp Select Switch.

Rotating the knob turns the lamps on and off in sequence.

Dmx

If the unit has Dmx control, the on-board as well as any remote dimmer attached will be disabled once Dmx cables are applied.

For manual control with Dmx cables plugged in, set address to "000". There is 5 second delay when switching between Dmx and manual control.

Environmental: Disposal of Old Electrical & Electronic Equipment.



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. This product is made of recyclable materials and should be disposed of in accordance with local and state regulations.

Kino Flo, Inc. 2840 N. Hollywood Way, Burbank, CA 91505, USA
Tel: 818 767-6528 website: www.kinoflo.com