


## **EXP-FXR-S**FIXTURE WIRE REPAIR KIT (Silver)

## **OLD HINGE REMOVAL:**

UNSCREW THE SET SCREWS FROM EACH END AND PULL OUT THE DAMAGED HINGE WIRE FROM THE SILVER CONDUIT. SAVE THE SET SCREWS FOR RE-INSTALLATION.

## **NEW HINGE WIRE INSTALLATION**



2) Flatten fixture. Cut the new hinge wire 3/4" (19 mm) shorter than the total length of the fixture.



3) Pass new hinge wire through silver conduit channel until it reaches the set screw.



NOTE: DO NOT FLEX THE FIXTURE UNTIL THE HINGE WIRE IS COMPLETELY INSTALLED!

4) Install a set screw at opposite end to secure the wire.

